

Material

Type

when using Victoria boards.

No.



Gap Between

Boards mm

Colour



Number of Clips

Needed per sa/m



Clip Code



Screw Code

Screws

Included

1	Starter Clip	Stainless Steel	Silver	0	10	N/A	66SC01	Yes	N/A
2	Double Clip	Stainless Steel	Silver	1.5	50	18	66DC01	Yes	N/A
3	Double Clip	Plastic	Black	7	100	18	70FCP01	Yes	N/A
4	Starter Clip	Stainless Steel	Black	7	1	N/A	71SC003	No	71SS003*
	Starter Clip	Stainless Steel	Black	0	25	N/A	71SC003P	No	71SS003*
5	Double Clip	Stainless Steel	Black	7	1	18	71DC003	No	71SS003*
	Double Clip	Stainless Steel	Black	7	100	18	71DC003P	No	71SS003*
6	Double Clip	Nylon	Black	7	100	18	71DCN003P	No	71SS003*
*Supplied in a pack of 100. For screw driver bit use code: 66TX001 .									

NB. We recommend 9 clips per board length when using Natural and Classic boards and 12 clips per board length

Number of Clips

per Pack

We also recommend using 10 starter clips per perimeter/starter board across the range.