GATE BUMP STOP



- Prevent gates slamming shut by installing this gate bump stop
- Made of rubber to reduce the noise made when a gate closes
- Simply screw into the gate stop

PRODUCT DETAILS

Product code: Description:


05SBS 18mm diameter x 7mm buffer

Thread size M6 x 16



INSTALLATION

1. Drill a 7mm hole in your gate stop and insert the bump stop, securing using the M6 nut provided.



Whilst every effort has been made to ensure the accuracy of the information supplied. F.H. Brundle cannot be held responsible for any errors or omissions. This product must only be employed for its original intended use. Any other use is wrong and potentially dangerous. Installation must be carried out in full compliance with current regulations. F.H. Brundle cannot be held liable for any damages resulting from wrongful, erroneous or negligent use.

